


CABEÇOTE FRESADOR

SPMT



Código	Dc	d	L	Nº Cortes	Ap (tam. Inserto)
BT990-40-3	40	16	42	3	09 a 10
BT990-40-4	40	16	42	4	09 a 10
BT990-50-3	50	22	50	3	09 a 10
BT990-50-4	50	22	50	4	09 a 10
BT990-50-5	50	22	50	5	09 a 10
BT990-63-4	63	22	50	4	09 a 10
BT990-63-5	63	22	50	5	09 a 10
BT990-63-6	63	22	50	6	09 a 10
BT990-80-6	80	27	50	6	09 a 10
BT990-80-8	80	27	50	8	09 a 10
BT990-100-6	100	32	50	6	09 a 10
BT990-100-7	100	32	50	7	09 a 10
BT990-100-8	100	32	50	8	09 a 10
BT990-100-9	100	32	50	9	09 a 10
BT990-125-8	125	40	60	8	09 a 10
BT990-125-7	125	40	60	7	09 a 10
BT990-125-10	125	40	60	10	09 a 10
BT990-160-8	160	40	60	8	09 a 10
BT990-160-10	160	40	60	10	09 a 10
BT990-160-12	160	40	60	12	09 a 10

Código	Dc	d	L	Nº Cortes	Ap (tam. Inserto)
BT990-40-3	40	16	42	3	11 a 16
BT990-50-3	50	22	50	3	11 a 16
BT990-50-4	50	22	50	4	11 a 16
BT990-63-3	63	22	50	3	11 a 16
BT990-63-4	63	22	50	4	11 a 16
BT990-63-5	63	22	50	5	11 a 16
BT990-80-4	80	27	50	4	11 a 16
BT990-805	80	27	50	5	11 a 16
BT990-80-6	80	27	50	6	11 a 16
BT990-100-5	100	32	50	5	11 a 16
BT990-100-6	100	32	50	6	11 a 16
BT990-100-7	100	32	50	7	11 a 16
BT990-125-6	125	40	60	6	11 a 16
BT990-125-7	125	40	60	7	11 a 16
BT990-125-8	125	40	60	8	11 a 16
BT990-160-8	160	40	60	8	11 a 16
BT990-160-12	160	40	60	12	11 a 16
BT990-200-10	200	60	60	10	11 a 16
BT990-200-14	200	60	60	14	11 a 16

Medidas em milímetros (mm)