



SUPORTE FRESADOR

SEHT



Código	ø D	Z	ø D2	ø d1	L
BT555.1-25-2	25	25	120	2	9
BT555.1-32-2	32	25	150	2	9 e 12
BT555.1-40-2	40	32	150	2	12
BT555.1-40-3	40	32	150	3	9 e 12
BT555.1-50-4	50	32	150	4	9 e 12